


NOTE: SLIDE O-RING OVER ROTOR ASSEMBLY
SHAFT, THEN RECONNECT BEARING
AND HOUSING.

795-37514



Graymills

3705 N. Lincoln Avenue, Chicago, IL 60613 773-248-6825 fax 773-477-8673 www.graymills.com