

PARTS LIST FOR QD & QE SERIES PUMPS

REF	DESCRIPTION	QD3
1	Quick Release Screw	402-29792
2	Coupling	769-07931
3	Wave Spring	765-07934
4	Bearing, Sealed, 1-3/8 OD	760-09377
5	Shaft	560-29771-91
6	Bearing, Sealed, 1-9/16 OD	760-09379
7	Locking Collar	583-29794
8	Key	758-08118-81
9	BEARING HOUSING	402-29936

REF	DESCRIPTION	QE53
1	Quick Release Screw	402-29792
2	Coupling	769-07931
3	Wave Spring	765-07934
4	Bearing, Sealed, 1-3/8 OD	760-09377
5	Shaft	560-29771-91
6	Bearing, Sealed, 1-9/16 OD	760-09379
7	Locking Collar	583-29794
8	Key	758-08118-81

NOTE:

For impeller detail see Agitor pumping systems parts list no. 795-07270.

Quick release screw positions are reversed on QE Pumps.

