


Agitor® "Q" Type Pumps Parts List

For Models beginning with QH3, QH53 & QHC3



COMMON PARTS

REF.	PART NUMBER	DESCRIPTION
4	435-14636-11	Shaft Protector
6	660-24564-81	Cover Plate
7	525-13710-74	Impeller
8	459-28833	QH Vapor Diffuser Assembly
8A	603-26467	Thread Protector
9	538-15138-31	Safety Cap
9B	680-25800-11	Safety Cap Retainer
10	755-03193-81	Nut, Castle 1/4-28 NF, 18-8
14	567-20160-86	Retainer Thumb Screw
15A	586-14632-11	Locating Pin
16	586-14635-11	Handle
17	571-14630-41	Driver
20	573-14631-11	Shaft Nut
21	601-14623-11	Handle Bracket
22	601-15233-11	QH Wrench
24	615-14851-81	Mounting Plate
25	660-14628-11	Baffle Disc.
34	752-06146-12	C/S Soc. Hd. 5/16-18 x 1-1/4
35	751-05387-88	M/S Hex Hd. 1/4 - 20 x 3/8
35B	754-00595-12	Lock Washer 1/4, Split
36	752-02729-81	Cap Screw 3/8-16 x 3/4 Hex HD.
36A	754-00564-12	Lockwasher, 3/8 Split
(Not Shown)	753-03235-12	Wing Screw, 3/8-16 NC x 1/2
44	756-00893-81	Pin, cotter
25A	570-28691-88	Sleeve
54	680-29280-81	Splash Plate
(Not Shown)	757-07515	Cap Plug for Agitor Jet

PARTS COMMON TO QH3 & QH53 MODELS

REF.	PART NUMBER	DESCRIPTION
5	504-24544-11	Volute
11	560-24624-86	Shaft
13	562-22204-86	Rod 5/8 Dia.
28	720-06518-13	Nipple 3/4 NPT x 13
41	754-03093-12	Flatwasher
46	765-03264-81	Spring

PARTS UNIQUE TO QHC3 MODELS

REF.	PART NUMBER	DESCRIPTION
5	439-25514-22	Volute Housing
11	560-24624-88	Shaft
13	562-22204-88	Rod 5/8 Dia.
28	720-02647-88	Nipple 3/4 NPT x 7
28A	724-00414-88	Coupling
41	754-03093-81	Flatwasher
46	570-28691-88	Sleeve